

SIPNA™ ZEO -131

Reference Manual



HART 
COMMUNICATION PROTOCOL



www.sipnaco.ir
info@sipnaco.ir

SIPNA™ ZEO -131

Reference Manual

General description

This series of temperature transmitter is a kind of intelligent type, used for field installation, with electrical isolation, support HART protocol. It receive signal then convert 4-20mA and stack HART signal output, like thermal resistance, thermocouple, resistance, millivolt.

The transmitter can field configuration through instrument panel button or HART hand operated device, also can through one USB interface HART modem to connect to PC configuration

Functional specifications

Thermal resistance / resistance

RTD thermal resistance

Pt100 / Pt1000 comply with IEC60751 standards

Resistance value

0...400

0...4000

Connecting cable

the biggest sensor circuit resistance of each line (RW) : 50

conform to NE89 (Jan 2009) specifications

second line circuit: Maximum compensation 100 line total resistance

Sensor fault signal

RTD: Short circuit and circuit breaker

Linear resistance measurement: circuit breaker

Thermocouple / voltage

Graduation No.

K, N, E, J, T, B, R, S comply with IEC60584 standards

Voltage value

-125...125mV

Connecting cable

the biggest sensor circuit resistance of each line (RW) : 1.5K , total resistance 3K

Input resistance

> 10M

Internal temperature compensator

Pt100, IEC 60751 C1.B

Sensor fault signal

Thermocouple: circuit breaker

Linear voltage measurement: circuit breaker

Transmission characteristics

output into a linear with temperature, resistance, voltage

Output signal

4-20mA stack HART digital signal

Fault current signal

	Standard
Linear output	$3.9 \leq I \leq 20.5$
"high" fault	$20.5 \leq I \leq 21.75$ (default)
"low" fault	$I \leq 3.9$ (MCU fault)

Power supply (support reverse polarity protection)

Two wire system, power line is equal to the signal line

The supply voltage


the working voltage is 12-35V



Load resistance

$R_{load} = (E-12) / 0.0236$

E is the power supply voltage



Basic information

Electrical insulation

1KV AC (input / output)

Input filter

50 / 60 HZ

Damping time

can be set 1-32S, default is 1s

refresh rate

≤ 0.5S

Operating temperature

-40°C - 85°C

when the temperature is lower than -30°C, LCD could not display as normal, and the display update rate will be reduced

Transport / storage temperature

-50°C - 85°C

Maximum permissible humidity

5-100% RH

Physical specifications

Outline dimension

See section size of section 6th

Joint box compound

Low copper aluminum die-casting

Color

Blue RAL9002



www.sipnaco.ir

info@sipnaco.ir

SIPNA™ ZEO -131

Reference Manual

Install
The transmitter can be mounted directly to the sensor
it also can be achieved through the installation of remote installation support

Electrical connection
Two-exit with M20*1.5 or NPT1/2 (through by transfer joint)

Protection level
IP66 and IP67

Weight
1KG

Performance specifications

Measurement accuracy
See table 1 in page 2

Cold end compensation precision
Pt100 DIN IEC 60751 C1.B, 0.3°C (Just for thermocouple)

Ambient temperature effect
See table 1 in page 2

Power effect
Power supply effects caused by voltage per volt is 0.005%

Stability
0.1 or 0.1% of temperature transmitter reading in 12 months (with large value)

Seismic performance
In the process of transportation and working, 10-60 HZ 0.21mm displacement
60-2000 HZ 3g

Electromagnetic compatibility
Conform to IEC61326 (2006) and NAMUR NE21 grade requirement

Table 1 Measurement accuracy and ambient temperature effect

Standard	Sensor	Measuring range	Measurement accuracy ¹⁾		Ambient temperature effect by each 1°C ²⁾	
			Fixed	Range	Fixed	Range
Thermal resistance / resistance						
IEC60751	Pt100	-200 ... 850 °C	±0.1°C	±0.1%	±0.006 °C	± 0.004%
	Pt1000	-200 ... 850 °C	±0.1°C	±0.1%	±0.006 °C	± 0.004%
	Resistance measurement	0 ...400Ω	0.035Ω	±0.1%	0.028Ω	± 0.004%
	Resistance measurement	0 ...4000Ω	0.35Ω	±0.1%	0.028Ω	± 0.004%
Thermocouple / voltage						
IEC60584	N	-270 ... 1300 °C	±0.8°C	±0.1%	±0.02 °C	± 0.004%
	K	-270 ... 1372 °C	±0.8°C	±0.1%	±0.02 °C	± 0.004%
	E	-270 ... 1000 °C	±0.8°C	±0.1%	±0.02 °C	± 0.004%
	J	-210 ... 1200 °C	±0.8°C	±0.1%	±0.02 °C	± 0.004%
	T	-270 ... 400 °C	±0.8°C	±0.1%	±0.02 °C	± 0.004%
	B	0 ... 1820 °C	±1°C	±0.1%	±0.06 °C	± 0.004%
	R	-50 ... 1768 °C	±1°C	±0.1%	±0.06 °C	± 0.004%
	S	-50 ... 1768 °C	±1°C	±0.1%	±0.06 °C	± 0.004%
	Voltage measurement	-125 ... 125 mv	0.02mv	±0.1%	0.001mv	± 0.004%

Remarks: 1) The measurement precision is the large value of the fixed value and the measuring range

2) The influence of environmental temperature change is the large value of the fixed value and the range value

Man-machine interface



Graphic controlled by the transmitter (alphanumeric) LCD display

Character height depends on the mode

Sign, 4 digit, 2 decimal places

Bar chart display

Angle of arbitrary rotating LCD display

Display options

Sensor process data

Sensor electrical data (ohm / mV)

Electronic components / ambient temperature

Output value

Output rate %

Display diagnostic information associated with the status of the transmitter and sensor

F002







www.sipnaco.ir


info@sipnaco.ir


SIPNA™ ZEO -131

Reference Manual

Using  and  button can browse the menu or select a parameter value or character.

Different functions assigned to  and  buttons. The function that is currently assigned to these buttons is displayed on the display screen..

	Meaning
Exit	Exit the menu
Back	Return to a sub menu
Cancel	Cancel parameter input
Next	Select the numeric value and the next bit of the letter

	Meaning
Select	Select sub menu / parameter
Edit	Edit parameter
OK	Save input parameter


2.2.3 Menu Tree

Step 1, press  button enter the main menu. Press  or  button can browse the menu, the menu is selected to light black form.



MAIN MENU: main menu
 SENSOR-TYPE: the type of sensor
 SENSOR-RANGE: the range of sensor
 DEVICE-INFO: transmitter information
 DAMPING: damping
 SAVE SET: save settings

Step 2, press  button get into sub menu of SENSOR-TYPE, press  or  button can choose different type of sensor, the sensor type is selected in the form of bright black



01 PT100 (IEC751): thermal resistance, graduation number Pt100
 02 PT1000 (IEC751): thermal resistance, graduation number Pt1000
 03 RES (0-400): resistance input 0-400Ω
 04 RES (0-4000): resistance input 0-4000Ω
 05 TC-B (IEC584): thermocouple, graduation number B
 06 TC-E (IEC584): thermocouple, graduation number E
 07 TC-J (IEC584): thermocouple, graduation number J
 08 TC-K (IEC584): thermocouple, graduation number K
 09 TC-N (IEC584): thermocouple, graduation number N
 10 TC-R (IEC584): thermocouple, graduation number R
 11 TC-S (IEC584): thermocouple, graduation number S
 12 TC-T (IEC584): thermocouple, graduation number T
 13 mV (-125-125) : voltage input, -125-125mV
 Factory Reset: factory reset




www.sipnaco.ir
 info@sipnaco.ir


SIPNA™ ZEO -131

Reference Manual

Step3, press  button get into sub menu of WIRE MENU (connection menu), press  or  button can choose different way of connecting mode, the connecting mode is selected in the form of bright black

	<p>WIRE MENU: connection menu 02 2-Wire: two-wire 03 3-Wire: three-wire 04 4-Wire: four-wire *Thermal resistance choose different way of connection mode according to need, usually it is 3-wire *Thermocouple is 2-wire</p>
---	--

Step4, press  button to back the main menu, press  button get into sub menu of SENSOR-RANGE, setting the sensor range

	<p>URV: range up limit LRV: range low limit</p>
---	---

Press  button can move the number of digits which need to adjust, it is showed by the  icon on the LCD display

Press  or  button can decrease or increase number (press  button to zero, continue to press it, it will show negative numbers signs)


Step5, press  button to back the main menu, jump to the step7 or press  button can get into sub menu of DEVICE-INFO (transmitter information), can see the equipment information of the transmitter (users do not need to get into this menu usually)

	<p>Date: 2014-06-01 date Hardware: Ver 5.0 hardware version number Software: Ver 2.0 software version number Device ID:> 062102 equipment information</p>
---	--

Step6, press  button back to the main menu, jump to the step7 or press  button can get into sub menu of DAMPING, press  or  button increase or decrease the damping time of transmitter. (usually the default time is 2s, user do not need to reset it anymore)

	<p>2.0 (Sec): damping time 2 seconds</p>
---	--

Step7,press  button back to the main menu, press  button can get into sub menu of SAVE SET, press  button save all configuration, continuity press  button back to the display interface.

	<p>TYPE: Pt100 thermal resistance WIRE: 3-wire URV: 0200.000 (unit) LRV: 0000.00 (unit) DAMP: 2.0 (Sec)</p>
---	---




www.sipnaco.ir
info@sipnaco.ir



SIPNA™ ZEO -131

Reference Manual

Electrical wiring



Outline dimension



HART
COMMUNICATION PROTOCOL



www.sipnaco.ir
info@sipnaco.ir